ArduTouch Music Synthesizer Assembly Instructions



m

rev

ArduTouch Music Synthesizer Assembly Instructions

m

Pev.

Note:

These assembly instructions are modified from the instructions for assembling the rev A board, so please don't get confused when you see some photos that are similar, but a little different than your rev B board.



http://mightyohm.com/soldercomic download for free at:

earn To Solder



Download in the language of your choice for free at: http://mightyohm.com/soldercomic





Download in the language of your choice for free at: http://mightyohm.com/soldercomic





R1: Brown, Black, Orange

(<u>not</u> Brown, Black, Red) 🗲



Bend leads before inserting the part into the board







Upside down/

Wires bent half way out



How to hold a soldering iron

(Like a pencil – held from underneath)

The perfect kind of solder for electronics: 60/40 rosin core, 0.031" diameter (or smaller)

3 Safety Tips...

Safety Tip #1:

Hot !!

Safety Tip #2:

Lead (Pb) is toxic But it easily washes off your hands with soap and water

Safety Tip #3:

(coming soon)

2 secrets to good soldering...

Secret #1: Clean the tip! (before every solder connection) Bang 3 times, Swipe, Rotate, Swipe: Keep the tip shiny silver!

Lay clean tip across half of the pad, touching the pad and lead for 1 second





Make sure solder melts on the underside of the soldering iron (not the side or top of the soldering iron tip)!

Pull solder away, But keep holding soldering iron down for 1 more second

Secret #2:

Keep hot tip down 1 second for solder to flow !!





If you can see any of the pad, or the hole, you need more solder – so, just do all the steps again to make it perfect.

Hold the lead while cutting it all the way down to the little bump of solder

Cutting with the tip of the wire cutter gives you more control

Safety Tip #3:

Hold or cover the lead !

All done !

No wire sticking out



One part at a time
Till all the parts are soldered



And it will look like this when you're done.

Let's start!



If you haven't done so already, solder R1: brown, black, orange

R1: R2, R3, R4, R5: R6, R7: R8, R9: R13, R14, R15:



10K: Brown, Black, Orange
22M: Red, Red, Blue
270: Red, Violet, Brown
4.7K: Yellow, Violet, Red
1K: Brown, Black, Red











bend pins down on corners, and solder all 28 leads to the board





C1, C2, C4, C5













C3, C8: Long Lead "+"



C3, C8: 100uF





C6, C7: Long Lead "+"



LED1, LED2, LED3: Long Lead "+"





We'll use them for the speaker

in the second se







Short leads into board



J1

(if it falls out, solder one lead on the top of the board, then turn over the board and solder the other 5 leads)



J1



S1: black Reset button

S2, S3: Red buttons



on the rev B board these are side by side (instead of on top of each other)



X1















bend pins down on corners, and solder all 8 leads to the board



R10: volume control



on the rev B board, R10 lays flat (and the pins don't fit in the holes well, so just push it in as far as it goes without forcing it, and solder)



J3: headphone / output jack






Use two thumbs to push microcontroller into the socket



















Battery pack



Done!



Let's make noise!

