I Can Solder Badge kit

Mitch Altman

Chief Scientist, Cornfield Electronics, San Francisco, CA

Inventor of TV-B-Gone universal remote controls

Co-founder of 3Ware (successful Silicon Valley startup)

Pioneer of VR (in the mid-1980s)

Founding mentor at HAX (1st and biggest hardware accelerator)

Co-founder of Noisebridge (San Francisco hackerspace)

email: mitch@CornfieldElectronics.com

site: www.CornfieldElectronics.com

facebook: maltman23

flickr: maltman23

WeChat: mitchaltman

Fediverse: @maltman23@mastodon.social

Patreon: mitchaltman





I Can Solder Badge kit

Assembly Instructions mitch@CornfieldElectronics.com






cornfield electronics


Syllabus

- How to solder
- Wear a blinky-light everywhere you go!

(Don't bring these home)

Tools






The following photos will show you how to solder.

But feel free to download the "Soldering Is Easy" comic book for free!


(In many different languages.)

http://mightyohm.com/soldercomic download for free at:

Learn To Solder



Learn To Solder



earn To Solder




Learn To Solder




Learn To Solder





All of the parts



The board we'll solder the parts to (front)







I Can Solder Badge

NOTE: This is the back of the board (the other side is the front)

How to:

Insert Pin in the front, solder it on the back.

Insert Battery Holder in the back, solder it on the front.

Insert Slide Switch in the front, solder it on the back, and the trim leads.

*** cornfield electronics

- t

Insert Push Button Switch in the front, solder it on the back.

W285637AS1F1

battery holder



Long leads of LEDs are (+):

Insert White LED in the front, solder it on the back, and trim the leads.

Insert Blinky LED in the front, solder it on the back, and trim the leads.

Insert Battery (+) side up.

Enjoy!


The board we'll solder the parts to (back)



Since we will use Sology So ir is helprin Tilly paste in a stringe Anorsoon Alconon

The tools you'll need:


- soldering Iron (35W or less)
- solder (more details coming)
- soldering iron stand
- cellulose kitchen sponge (not plastic!)



The following slides will show you how to solder a resistor.


There is no resistor in this kit. But the soldering procedure is the same for all of the parts in this kit.

The "I Can Solder Badge" kit has no resistors




(but, the parts in this kit are soldered the same way)


The "I Can Solder Badge" kit has no resistors




this is how a resistor will look *before* inserting it into the board

LEDs for this kit go into the board like this resistor







so that the part won't fall out while soldering it



How to hold a soldering iron

(Like a pencil – held from underneath)



The best kind of solder for DIY electronics:

(Sn - Tin / Pb - Lead)

(60/A0 is also 9000) 63/37 rosin core,

0.031" (0.8mm) diameter (or smaller)

Note:

Most

Lead-Free solder has poisonous fumes!

This is what we will use:

A good kind of solder for DIY electronics:

This is the only good searching)



Kester
K100LD Rosin
(not "No Clean")

0.031" diameter (0.8mm)

This is what we will use:

A good kind of solder for DIY electronics:

This is the only good

solder I have found!

(after years of searching)

And Isopropyl Alcohol



Kester K100LD Rosin Solder

0.031" diameter (0.8mm)


Note:

Since we will use Lead-Free solder it is helpful to also have flux paste in a syringe



Another good kind of solder for DIY electronics:

This is another good Lead-Free solder I have found!



Duratool D01685 Rosin

0.7mm diameter

(as good as the Kester K100LD Rosin)

Another good kind of solder for DIY electronics:

This is another good solder I have found!



MG Chemicals 4900 Rosin (112g, 227g, 454g)

0.8mm diameter

(as good as the Kester K100LD Rosin)

3 Safety Tips...

Safety Tip #1:

Hot!!

(When you touch the tip, you will let go quickly every time!)

Safety Tip #2:

Soldering chemicals are toxic

But they easily wash off your hands with soap and water

Safety Tip #3:

(coming soon)

2 secrets to good soldering...


Secret #1:

Clean the tip!


(before every solder connection)

Bang (lightly) 3 times, Swipe, Rotate, Swipe (on the sponge):

Keep the tip shiny silver!




Do this quickly (slowly doesn't work well) – solder in & out in about 1 second




Make sure solder melts on the <u>underside</u> of the soldering iron tip (not the side or top of the soldering iron tip)!

Do this quickly (slowly doesn't work well) – solder in & out in about 1 second





Make sure solder melts on the <u>underside</u> of the soldering iron tip (not the side or top of the soldering iron tip)!



Secret #2:

Keep hot tip down
1 second
for solder to flow!!






If you can see any of the pad, or the hole, you need more solder – so, just do all the steps again to make it perfect.

is just as important as the preceding steps!

The Rhythm! and speed (about 1 second per step)



and speed (about 1 second per step)

Clean the tip



and speed (about 1 second per step)



Tip Down

and speed (about 1 second per step)



Solder In

The Rhythm! and speed (about 1 second per step)



Solder Out

and speed (about 1 second per step)






The Rhythm! and speed (about 1 second per step)





The Rhythm! and speed (about 1 second per step)



and speed (about 1 second per step)

Clean the tip



and speed (about 1 second per step)



Tip Down

and speed (about 1 second per step)




Solder In

The Rhythm! and speed (about 1 second per step)



Solder Out

and speed (about 1 second per step)






The Rhythm! and speed (about 1 second per step)






Solder all of the leads of the part to the board




For this part, there are two leads
Here you can see two good solder connections

Two good solder connections



- Little mountains (not flat)
- Pads totally covered in solder
- Can't see the hole
- No connections to other pads

Now cut the leads short




Cutting with the tip of the wire cutter gives you more control

Safety Tip #3:


Hold or cover the lead!

(or it will fly into your eye!)

(They like doing that – so please hold or cover the lead when you cut.)



No wires sticking out



A closer look at good solder connections

Notice that:

- Each connection
 is a small mountain
 (not flat)
- You cannot see any pad
 (they're totally covered
 with solder)
- You cannot see the holes

 (they're totally covered with solder)
- No connections to other pads

One part at a time


Till all the parts are soldered



And it will look like this when you're done.

If you used any flux paste for re-working problems







You can clean it with a cloth wet with Isopropyl Alcohol

Then put in the batteries,

Turn it on,

And it works!


(Or you start debugging.)

Let's start!


Insert Pin in the front



Solder Pin on the back




Insert Battery Holder in the back




The correct orientation of the battery holder is like this photo

Solder Battery Holder on the front (1st pad)



Solder Battery Holder on the front (2nd pad)



Insert Slide Switch in the front



Orientation does not matter

Solder Slide Switch on the back (1st pad)



Solder Slide Switch on the back (2nd pad)



Solder Slide Switch on the back (3rd pad)



Trim Slide Switch leads (1st lead)



REMEMBER:

Cover the lead with your finger when you cut !


Trim Slide Switch leads (2nd lead)



REMEMBER:

Cover the lead with your finger when you cut!

Trim Slide Switch leads (3rd lead)



REMEMBER:

Cover the lead with your finger when you cut!

Insert Push Button Switch in the front




It fits in two ways, and either way is OK


Solder Push Button Switch on the back (1st pad)



Solder Push Button Switch on the back (2nd pad)




Solder Push Button Switch on the back (3rd pad)



Solder Push Button Switch on the back (4th pad)




Test each LED to see which is the White LED and which is the Blinky LED



White LED

Long lead is "+"


Test each LED to see which is the White LED and which is the Blinky LED



Blinky LED


Long lead is "+"

Insert White LED in the front



Long lead is "+"

Insert White LED in the front




Leads of White LED bent like a "V"



Solder White LED on the back (1st pad)



Solder White LED on the back (2nd pad)



Trim White LED leads (1st lead)



lead when you cut! Hold the

Trim White LED leads (2nd lead)




Insert Blinky LED in the front




Short lead is a sure of the su


Insert Blinky LED in the front



Leads of Blinky LED bent like a "V"




Solder Blinky LED on the back (1st pad)




Solder Blinky LED on the back (2nd pad)



Trim Blinky LED leads (1st lead)




Trim Blinky LED leads (2nd lead)



You are now finished soldering!

If you used any flux paste for re-working problems







You can clean it with a cloth wet with Isopropyl Alcohol

Insert Battery (+) side up





Insert Battery (+) side up



All done!




Turn on **Blinky** LED!



Move Slide Switch to the left to turn on the Blinky LED

Turn on White LED!



Press Push Button Switch to turn on the White LED

Turn on both White and Blinky LED!



Wear it!



Please Remember:

to
Wash your hands
after soldering

I Can Solder Badge kit

Assembly Instructions mitch@CornfieldElectronics.com





cornfield electronics

I Can Solder Badge kit

Mitch Altman

Chief Scientist, Cornfield Electronics, San Francisco, CA

Inventor of TV-B-Gone universal remote controls

Co-founder of 3Ware (successful Silicon Valley startup)

Pioneer of VR (in the mid-1980s)

Founding mentor at HAX (1st and biggest hardware accelerator)

Co-founder of Noisebridge (San Francisco hackerspace)

email: mitch@CornfieldElectronics.com

site: www.CornfieldElectronics.com

facebook: maltman23

flickr: maltman23

WeChat: mitchaltman

Fediverse: @maltman23@mastodon.social

Patreon: mitchaltman



