Arduino For Total Newbies w/TV-B-Gone as example project

Mitch Altman

Chief Scientist, Cornfield Electronics, San Francisco, CA

Inventor of TV-B-Gone universal remote controls

Co-founder of 3Ware (successful Silicon Valley startup)

Pioneer of VR (in the mid-1980s)

Founding mentor at HAX (1st and biggest hardware accelerator)

Co-founder of Noisebridge (San Francisco hackerspace)

email: mitch@CornfieldElectronics.com

site: www.CornfieldElectronics.com

facebook: maltman23

flickr: maltman23

WeChat: mitchaltman

Fediverse: @maltman23@mastodon.social

Patreon: mitchaltman





PLEASE open annumber

Arduino For Total Newbies

w/TV-B-Gone as example project

Bring all of this home with you!


Stuff!



extra parts



USB-Serial cable



U-Do-It-Duino kit




Parts Pack

Syllabus


- Intro
- Everything You Need to Know About Electronics
- How to solder / make your own Arduino
- How to Set Up and Use the Arduino Software
- How to Hack Arduino Programs ("Sketches")
- How to Use Solderless Breadboards
- How to Read a Schematic
- Make a TV-B-Gone Remote Control with your Arduino Clone without soldering

(Don't bring these home)


Tools





Intro





























Everything You Need to Know About Electronics
















Solder Your Aruino Clone



How to Set Up and Use the Arduino Software




How to Hack Arduino Programs ("Sketches")




How to Use Solderless Breadboards

Solderless Breadboard



How to Use Solderless Breadboards

Solderless Breadboad with LED and wires



a Schematic How to Read


Arduino For Total Newbies

Mitch Altman (original TV-B-Gone hardware and firmware, modified TV-B-Gone Arduino design) Limore Fried (firmware modifications, kit design)




Johannes Schneemann (documentation)







Make a TV-B-Gone Remote Control with your Arduino Clone without soldering

Solderless Breadboard with parts & wires for TV-B-Gone





Questions?


















Intro




Arduino For Total Newbies Workshop at 30C3, Hamburg Germany

Intro to Arduino






A complete computer on a chip



A complete computer on a chip: they control parts connected to their pins





ArduTouch music synthesizer kit













TV-B-Gone







TV-B-Gone


Just a remote control,
but only one button:

OFF!






TV-B-Gone



A complete computer on a chip: they control parts connected to their pins

Intro to Arduino: microcontrollers



But,

How do you connect parts to its pins?

A complete computer on a chip:

they control parts connected to their pins

How do you create and upload a program to control the parts?

Intro to Arduino: microcontrollers



A complete computer on a chip:


they control parts connected to their pins

But,

How do you connect parts to its pins?

How do you create and upload a program to control the parts?

Answer: Be a geek, and learn how!



Use an Arduino board



Super easy to connect parts to its microcontroller's pins

Use an Arduino board



Super easy to connect parts to its microcontroller's pins


Use an Arduino beard

Super easy to create and upload a program to control the parts




Arduino board


Designed for non-geeky artists





Many Arduino boards to choose from
























































Arduino "Clones"









"Arduino-Compatible"

ArduTouch music synthesizer kit





Intro




Intro

Questions?





Electrons




Circuit = Electrons going in complete circle = Magic!













Power Supplies





Voltage / Volts




Electrons pushed with 1.5V. So, they move!


Current / Amps








Current / Amps












Ohm's Law

Volts -- force pushing electrons

Amps -- speed of electrons

Ohms -- Resistance to flow of electrons




Ohm's Law

Volts -- force pushing electrons

Amps -- speed of electrons

Ohms -- Resistance to flow of electrons




Ohm's Law

Volts -- force pushing electrons

Amps -- speed of electrons

Ohms -- Resistance to flow of electrons




 $V_{olts} = A_{mps} \times R$


Also commonly written: $E = I \times R$


The symbol for Resistance:


Ω



Resistor / Ohms








Resistor / Ohms




What happens?

Polarity


Power Supply – it matters how you connect it!



Power Supply – it matters how you connect it!




Power Supply – it matters how you connect it!



(electrons slowed down the same either way)

Resistors – it doesn't matter which way

Minus / Negative side



Minus / Negative side

Diodes - One-Way valve for electrons

Diodes – it matters which way!




Short wire is Minus / Negative

Special kind of Diode — it Emits Light!

LED – it matters which way!



Lots of different colored LEDs! (including IR)



More current → More brightness! (until...)




More current → More brightness! (until...)




(with a resistor so no magic smoke goes away)

This is why we put a resistor in line with an LED




(the resistor can go on either side)


This is why we put a resistor in line with an LED





Series = in line


Parallel = across





















It lights!
LED





It's off
LED





LED & battery


Our first circuit












A "code" is IR light blinking on-off-on-off...

IR Remote Control




A "code" is IR light blinking on-off-on-off...

(we can't do this, but microcontrollers can!)


IR Remote Control

Takes about 60 seconds



About 150 IR "OFF" codes (one per blink)


TV-B-Gone universal remote control



Short wire is Minus / Negative

Little buckets for electrons


Capacitor / Farads



Short wire is Minus / Negative

Little buckets for electrons

Capacitor / Farads




Strips of metal connected together – or not

Switch




A complete computer on a chip

Microcontroller




that control electronic parts connected to its pins.

Microcontroller



A complete computer on a chip


Microcontroller – it matters how you hook it up!



A complete computer – running a program!

Microcontroller – turned on!

all other pins are
Input pins
or
Output pins



Your program controls electronics parts on these other pins

Microcontroller

Analog Electronics:

Any voltage between Ground (0V) and Vcc

Digital Electronics:

Only 2 choices: Ground (0V) or Vcc

2 types of electronics


```
Ground (0V)

Low
Off
On
O
(without Voltage / with Voltage)
(without current / with current)
```

Digital Electronics:
Only 2 choices: Ground (OV) or Vcc

Digital Electronics

To make a pin an Output pin



you tell it to become an Output pin with a statement in your program

Let's tell pin 13 to be an Output pin

Microcontroller – Output pins

Off On

(OV) (Power supply voltage)
-- like the Red wire of our power supply
-- but controlled by our program!

Only 2 choices: High or Low

Microcontroller – Output pins

A real world example

How to make an LED blink?

Hello World

Software

Type:


Hello World

on your screen

Microcontrollers

make an LED blink


Hello World




Turning an LED on and off

Let's replace the power supply


Turning an LED on and off




Turning an LED on and off




Turning an LED on and off




Turning an LED on and off



Turning an LED on and off




Turning an LED on and off




Turning an LED on and off

This is our Hardware for Hello World!




Turning an LED on and off




Turning an LED on and off

Programs on microcontrollers are called "Firmware"




Turning an LED on and off


Programs on microcontrollers are called "Firmware"




A programs for Arduino is called a "Sketch"


Turning an LED on and off













We now have Hello World





Microcontrollers – they go really fast!

Hardware




Firmware

- pin 13 is Output pin
- set pin 13 High
- delay
- set pin 13 Low

Hello World-forreal now!

Microcontroller – Firmware

Hardware



Firmware

- pin 13 is Output pin
- set pin 13 High
 - delay
 - set pin 13 Low
 - delay

Hello World-forreal now!

Microcontroller – Firmware



A precision cut piece of quartz crystal

For precise timing


Crystal / Hertz



Frequency, measured in Hertz

For precise timing (but less than a crystal)

Crystal / Hertz




A bunch of resistors and capacitors

For precise timing (but less than a crystal)

Ceramic Resonator / Hertz


Hardware



Firmware


- pin 13 is Output pin
- set pin 13 High
- delay
- set pin 13 Low

Let's hack Hello World!




Add an IR LED to another pin

IR "OFF" codes




Add an IR LED to another pin (say, pin3)

IR "OFF" codes




Add an IR LED to another pin (say, pin3) and a resistor so no magic smoke goes away

IR "OFF" codes




But, When?

IR "OFF" codes




Let's add an Input pin!

and
We can add a Start button




Microcontroller – Input pins




only 2 choices – is the Input pin: High or Low?

Microcontroller – Input pins



Low

Microcontroller – Input pins




High




FYI:
Wire color does not matter!


(electrons don't care)

High




High





If firmware looks at
Pin 2 when it's like this,
it reports back:


Low




If firmware looks at
Pin 2 when it's like this,
it reports back:

High


Reading the Input pin




Reading the Input pin, with Switch



Reading the Input pin, with Switch




Reading the Input pin, with Switch



Reading the Input pin, with Switch

Hardware



Firmware

Pin 13 Output – visible LED pin
Pin 3 Output – IR LED pin
Pin 2 Input – Push Button

Wait for Switch to be Low

Blink visible LED:

High, Delay, Low
Pulse IR LED for Sony "OFF" code:
High, Delay, Low, Delay...

Blink visible LED:


High, Delay, Low
Pulse IR LED for Panasonic "OFF" code:
High, Delay, Low, Delay...

Etc for all "OFF" codes

TV-B-Gone remote control

Microcontroller

Hardware



Firmware

Pin 13 Output – visible LED pin
Pin 3 Output – IR LED pin
Pin 2 Input – Push Button

Wait for Switch to be Low

Blink visible LED:

High, Delay, Low
Pulse IR LED for Sony "OFF" code:
High, Delay, Low, Delay...

Blink visible LED:


High, Delay, Low
Pulse IR LED for Panasonic "OFF" code:
High, Delay, Low, Delay...

Etc for all "OFF" codes


TV-B-Gone remote control


Microcontroller

Remember:



More current → More brightness! (until...)





So,


let's amplify the current

from the Output pin

with

a

Current amplifier!



Transistor

Hardware



Firmware

Pin 13 Output – visible LED pin
Pin 3 Output – IR LED pin
Pin 2 Input – Push Button

Wait for Switch to be Low

Blink visible LED:

High, Delay, Low

Pulse IR LED for Sony "OFF" code:

High, Delay, Low, Delay...

Blink visible LED:

High, Delay, Low

Pulse IR LED for Panasonic "OFF" code:

High, Delay, Low, Delay...

Etc for all "OFF" codes


TV-B-Gone remote control – we're done!

Microcontroller



And, that is Everything You Need to Know About Electronics

Questions?




The following photos will show you how to solder.

But feel free to download the "Soldering Is Easy" comic book for free!

(In many different languages.)


http://mightyohm.com/soldercomic download for free at:

Learn To Solder




http://mightyohm.com/soldercomic (In many different languages.) download for free at:

U-Do-It-Duino – we will solder this!




PLEASE OPEN OPEN! ON Whine yet! anything




These are: C2, C3


Set aside these 2 capacitors




Now,
please open
all of these parts




U-Do-It-Duino – we will **NOT** use all of these parts




Unused parts




Parts to use




Our first part to solder: R3




Top of Board



Bottom of Board



All Parts are soldered on the Top of Board!






Since we are using Soloe. in is been helpering. Flux Daske in a syringe Anortsopropriation Alcohol

The tools you'll need:


- soldering Iron (35W or less)
- solder (more details coming)
- soldering iron stand
- cellulose kitchen sponge (not plastic!)
- small wire cutter

Our first part to solder



(not Brown, Black, Red)


Some parts, such as resistors, need their leads bent first







R3 – this is how it will look *before* inserting it into the board

R3: Look down at the shape of this part



R3: Same shape as the actual resistor





R3: leads inserted into their pads



Push part down all the way

R3: board upside down



Bend leads half way out

(only half way) like a "V"

so that the part won't fall out while soldering it

R3: board upside down



Bend leads half way out

(only half way) like a "V"

Ready to Solder !



How to hold a soldering iron

(Like a pencil – held from underneath)



The best kind of solder for DIY electronics:

(Sn - Tin / Pb - Lead)

160/A0 is also 90000 63/37 rosin core,

0.031" (0.8mm) diameter (or smaller)

Note:

Most

Lead-Free solder has poisonous fumes!

A decent kind of solder for DIY electronics:

This is the only good

CHIPQUIK®
WW100Ge.031 1LB

100GeTM
Sn99.244
Cu0.7
Ni0.05
Ge0.006

No-Clean Water-Washable
2.2% Flux Core Solder Wire
0.031" (0.8mm)
Mfg Date (YYMDD): 240614
Lot: 625003-30642

solder I have found!

(after years of searching)

Chip Quik Germanium-Doped Solder

Sn99/Cu0.7/Ni0.05/Ge0.006

0.031" diameter (0.8mm)

A decent kind of solder for DIY electronics:

This is the only good

solder I have found!

(after years of searching)



Chip Quik **Germanium-Doped** Solder

Sn99/Cu0.7/Ni0.05/Ge0.006

0.031" diameter (0.8mm)

Note:

Since we will be using Lead-Free solder it is very helpful

to also have flux paste in a syringe

And Isopropyl Alcohol

3 Safety Tips...

Safety Tip #1:

Hot!!

(When you touch the tip, you will let go quickly -- every time!)

Safety Tip #2:

Soldering chemicals are toxic

But they easily wash off your hands with soap and water

Safety Tip #3:

(coming soon)

2 secrets to good soldering...


Secret #1:

Clean the tip!


(before every solder connection)

Bang (lightly) 3 times, Swipe, Rotate, Swipe (on the sponge):

Keep the tip shiny silver!




Do this quickly (slowly doesn't work well) – solder in & out in about 1 second




Make sure solder melts on the <u>underside</u> of the soldering iron tip (not the side or top of the soldering iron tip)!

Do this quickly (slowly doesn't work well) – solder in & out in about 1 second





Make sure solder melts on the <u>underside</u> of the soldering iron tip (not the side or top of the soldering iron tip)!



Secret #2:

Keep hot tip down
1 second
for solder to flow!!






If you can see any of the pad, or the hole, you need more solder – so, just do all the steps again to make it perfect.

is just as important as the preceding steps!

The Rhythm! and speed (about 1 second per step)



and speed (about 1 second per step)

Clean the tip



and speed (about 1 second per step)



Tip Down

and speed (about 1 second per step)



Solder In

The Rhythm! and speed (about 1 second per step)



Solder Out

and speed (about 1 second per step)






The Rhythm! and speed (about 1 second per step)





The Rhythm! and speed (about 1 second per step)



and speed (about 1 second per step)

Clean the tip



and speed (about 1 second per step)



Tip Down

and speed (about 1 second per step)



Solder In

The Rhythm! and speed (about 1 second per step)



Solder Out

The Rhythm!

and speed (about 1 second per step)






The Rhythm! and speed (about 1 second per step)






Since we are using *Lead-Free* solder: First add flux!



For Lead-Free solder, add flux to each pad before soldering!

For this part (R1) there are two pads


Since we are using Lead-Free solder: Add flux to the pads before soldering



Here you can see flux over each of the two pads.


Now these leads are ready to solder with your Lead-Free solder.

Solder all of the leads of the part to the board




For this part, there are two leads
Here you can see two good solder connections

Two good solder connections



- Little mountains (not flat)
- Pads totally covered in solder
- Can't see the hole
- No connections to other pads

Now cut the leads short




Cutting with the tip of the wire cutter gives you more control

Safety Tip #3:

Hold or cover the lead!

(or it will fly into your eye!)

(They like doing that – so please hold or cover the lead when you cut.)



No wires sticking out




A closer look at good solder connections

Notice that:

- Each connection
 is a small mountain
 (not flat)
- You cannot see any pad
 (they're totally covered
 with solder)
- You cannot see the holes (they're totally covered with solder)
- No connections to other pads

One part at a time


Till all the parts are soldered



And it will look like this when you're done.

Since we used Lead-Free solder and flux paste in a syringe

The bottom of the PCB will be sticky from the flux





You can clean it with a cloth wet with Isopropyl Alcohol


Then test with battery pack,


Turn it on,


And it works!

(Or you start debugging.)


Let's start!










C5: Long lead "+" (square pad)






C2 and C3 (The 2 capacitors you set aside)






Orientation of Microcontroller Socket




Orientation of Microcontroller Socket


Bend pins down on two opposite corners



- Solder all 28 pins.
- Only need to clean the tip after it gets dirty.
- No need to cut the pins short after soldering.




LEDs: Long lead "+" (square pad)




LEDs: Long lead "+" (square pad)

Short leads of the Serial Port Connector go into the board



Serial Port Connector: Long leads point to the left

Solder on top of board if it falls out upside down




Serial Port Connector

The white circle (or diamond)




The white circle (or diamond) goes in the square pad







The white circle (or diamond) goes in the square pad



RN1


The Reset Switch fits in 2 ways – either way is fine






Headers

It's easiest to solder all Headers at once. Insert, and hold them like this:




It's easiest to solder all Headers at once. Lay it all on the table:




Headers

Now it is easy to solder all of the Header pads at once.






You probably need to bend the pins so they're parallel




Microcontroller

You probably need to bend the pins so they're parallel




Microcontroller

You probably need to bend the pins so they're parallel




Microcontroller

Ready to insert into its socket




Microcontroller




Microcontroller

When all pins fit in their holes, use both thumbs to push chip into socket




Microcontroller

Each pin in its hole, chip pushed down all the way. Pin 1 is oriented correctly.




Microcontroller

We are done soldering!




First test:



Connect power with a battery pack...


First test:



... and it blinks!

Since we used Lead-Free solder and flux paste in a syringe


The bottom of the PCB will be sticky from the flux






You can clean it with a cloth wet with Isopropyl Alcohol

You now have your own Arduino!





Now we can connect parts to our Arduino, and program it!




Helpful info on the

Arduino for (4) Total Newbies


workshop web-page:

https://tinyurl.com/A4TNworkshop

USB-Serial Cable



USB-Serial Cable Driver



You may need to download and install a driver for your Operating System (Windows, MacOS, or Linux):

https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers

Helpful info on the

Arduino for (4) Total Newbies

workshop web-page:

https://tinyurl.com/A4TNworkshop



<u>File Edit View History Bookmarks Tools Help</u>

and see how your life can be enhanced. Love it or hate it, TV screens are all around us. TV-B-Gone® universal remote control is the first fruit of our technical savvy, embodying our belief in empowerment, and sense of humor. This

universal remote control fits in your pocket and allows you to discreetly turn TVs off wherever you go. TV-B-Gone fans around the world are using it for a variety of practical, philosophical, and humorous purposes. Imagine the possibilities...

Years in the making NeuroDreamer sleep mask is another of our personal empowerment inventions. We all need rest, but we don't always get it in our busy lives. NeuroDreamer sleep mask lets you use your own brainwaves to

bring you the rest you need. And with the lucid dreaming model, you can take control of your dreams.

Join our mailing list

show cart

Want to learn electronics? We make way cool, fun, intriguing, educational kits that anyone can make! Our most POPULAR kits are: ArduTouch music synthesizer kit and TV-B-Gone kit!

We make truly useful technological solutions that put you in charge.


Welcome to our better world!

NOTE: As of 14-Feb-2023 Cornfield Electronics is a sole proprietorship of Mitch Altman.

legal notices & privacy policy



to watch. Each of us can decide when to get the rest we want, and how we dream. Everyone can learn to make cool things with our kits. Please explore our products, make your own choices,





The TV-B-Gone Kit was originally developed from a MiniPOV3 hack (see below) (which, of course, I hacked from my original TV-B-Gone.)

For excellent assembly instructions, please go to the TV-B-Gone Kit page of the of the Adafruit.com website.

For questions about the TV-B-Gone Kit, please go to the TV-B-Gone Kit user forum. To see the schematic, firmware, and board layout, please go to TV-B-Gone Kit downloads.

TV-B-Gone Kits are available for **purchase** from the **TVBGone.com** website.

Project: Arduino For Total Newbies workshop -- Learn Arduino, and make your own TV-B-Gone!



This workshop covers lots of ground -- all you need to learn how to play with Arduinos. As an example project, you can make your own TV-B-Gone using Arduino. Many thanks to Ken Shirriff for the original TV-B-Gone for Arduino project! For documentation on this workshop, please see the: Arduino For Total Newbies Workshop page.






For **questions** about the TV-B-Gone Kit, please go to the <u>TV-B-Gone Kit user forum</u>.

To see the **schematic, firmware, and board layout**, please go to <u>TV-B-Gone Kit downloads</u>.


TV-B-Gone Kits are available for **purchase** from the **TVBGone.com** website.






This workshop covers lots of ground -- all you need to learn how to play with the amos. As an example project, you can make your own TV-B-Gone using Ardy Many thanks to Ken Shirriff for the original TV-B-Gone for Advisory Transfer of the content of this workshop, please the:

Arduino For Total Newbies Workshop page.





Arduino For Total Newbies Workshop

last updated: 1-May-2023


File Edit View History Bookmarks Tools Help


Learn how to make your own way cool projects with Arduino, using TV-B-Gone as an example project to learn from.



I've given this workshop at Noisebridge hackerspace in San Francisco (several times), at 27C3 and 28C3 in Berlin, and 29C3, 30C3, 31C3, 32C3, and 33C3 in Hamburg, and at 34C3, 35C3, 36C3 in Leipzig, and RC3 online, at CCCamp2011 CCCamp2015 and CCCamp2019 outside of Berlin, at HeatSync Labs hackerspace in Phoenix, AZ, at Fabelier hackerspace in Paris, at Unit One in 2012, 2014, 2016, and 2018 as Hacker In Residence at the University of Illinois, in Urbana, IL, at Makerspace Urbana in Urbana, IL in 2012 and in 2016, at Workshop Weekend in Oakland, CA (twice), at XinCheJian hackerspace in Shanghai, at Maker Carnival in Beijing (twice) at several conferences and hackerspaces on my Hackers on a Train Workshop Tour 2012 including at HOPE Number 9 in New York City, at ToorCamp 2012 in Neah Bay, WA, at OHM 2013 and SHA 2017 outside of Amsterdam, at RockIT CoLabs in San Francisco, at BalcCon2k14 in Novi Sad, Serbia, at HOPE X, The Eleventh HOPE, The Circle of HOPE A New HOPE in New York City, and HOPE 2020 online, at the iCenter as Hacker In Residence at Tsingua University in Beijing, at EMF Camp 2016, EMF Camp 2018, and EMF Camp 2022, outside of London, at Tami hackerspace in Tel Aviv, at Le Wagon and Zhongxi in Chengdu, at Astralship hackerspace in North Wales (three times), at Open Source Microfactory Build Camp online, at Newline in Ghent, at GPN20 in Karlsruhe, at Fri3d Camp 2022 near Sint-Joris-Weert, Belgium, at Maker Faire Brno 2022 in Brno, Czech Republic, at HiP-Berlin in Berlin, Germany, and lots of other places.

Each time 10 to 50 people show up. (Folks seem to like it.)






1) If you don't already have **Arduino software** you need to download it for your computer (Windows, Mac OS, or Linux):

<u>Arduino download page</u>

Arduino software:
Any version you have is fine!



Download the Arduino IDE


Windows Installer, for Windows XP and up **Windows** ZIP file for non admin install

2) You need a driver for your USB communications/programming cable. Several different ones are available. Choose the driver for the cable you have and the operating system for your computer.

Samurai Circuits board (SiLabs CP210x USB-to-Serial TTL) drivers:

The latest drivers from SiLabs' website

The SiLabs driver is installed by default on most Linux systems.



Silicon Labs » Products » Development Tools » Software » USB to UART Bridge VCP Drivers

CP210x USB to UART Bridge VCP Drivers

The CP210x USB to UART Bridge Virtual COM Port (VCP) drivers are required for device operation as a Virtual COM Port to facilitate host communication with CP210x products. These devices can also interface to a host using the direct access driver. These drivers are static examples detailed in application note 197: The Serial Communications Guide for the CP210x, download an example below:

AN197: The Serial Communications Guide for the CP210x

Download Software


The CP210x Manufacturing DLL and Runtime DLL have been updated and must be used with v6.0 and later of the CP210x Windows VCP Driver. Application Note Software downloads affected are AN144SW.zip, AN205SW.zip and AN223SW.zip. If you are using a 5.x driver and need support you can download archived Application Note Software.

Legacy OS software and driver package download links and support information


Download for Windows 10 Universal (v10.1.4)

3) You also need the TV-B-Gone Arduino Sketch (download this, unzip it, and copy it to your computer in the "examples" folder inside your "arduino" folder that you downloaded):


TV-B-Gone Arduino sketch(22KB)




4) Schematic Diagram for Arduino TV-B-Gone remote control: Schematic Diagram(449KB)



USB-Serial Cable



To computer's USB



no twists

After you download and install the Arduino software start it, and you will see a screen that looks like this:

```
sketch_may1a | Arduino IDE 2.1.0
                                                                                                        File Edit Sketch Tools Help
              Arduino Uno
     sketch_may1a.ino
              void setup() {
                // put your setup code here, to run once:
          3
          5
              void loop() {
                // put your main code here, to run repeatedly:
          8
          9
         10
```

The *first time* you start your Arduino software you need to do *two things* to set things up:

```
sketch_may1a | Arduino IDE 2.1.0
                                                                                                        File Edit Sketch Tools Help
              Arduino Uno
     sketch_may1a.ino
              void setup() {
          1
                // put your setup code here, to run once:
          5
              void loop() {
                // put your main code here, to run repeatedly:
          8
          9
         10
```

The *first time* you start your Arduino software you need to do *two things* to set things up:

(1) Choose "Uno" as the Board


(Your

<u>U-Do-It-Duino</u>

<u>acts</u>
<u>just like</u>


<u>an</u>

Arduino Uno board)



The *first time* you start your Arduino software you need to do *two things* to set things up:


Choose
the Port
(this will be
different
depending on
your Operating
System)



The *first time* you start your Arduino software you need to do *two things* to set things up:

Choose
the Port
(this will be
different
depending on
your Operating
System)

(After installing
the driver for
your USB-Serial cable,
and plugging it in
your operating system
will see a serial port
and it appears here.)



Choose the new port: In this example: COM18

The *first time* you start your Arduino software you need to do *two things* to set things up:

Your Arduino software is now ready

Designed for non-geeky artists

"Sketch":
an Arduino program

Designed for non-geeky artists

The Arduino language:

"Wiring"

(actually C/C++)


Your Arduino software is now ready to program your U-Do-It-Duino!


```
sketch_may1a | Arduino IDE 2.1.0
                                                                                                                 X
File Edit Sketch Tools Help
                                                                                                            √ .⊙.

♣ Arduino Uno

     sketch_may1a.ino
              void setup() {
                // put your setup code here, to run once:
包
          3
          4
              void loop() {
                // put your main code here, to run repeatedly:
          8
         10
                                                                                        Ln 1, Col 1 Arduino Uno on COM18 🚨
```


Your Arduino software is now ready to program your U-Do-It-Duino!








With the USB-Serial cable connected to your ArduTouch board press the Upload button



While uploading, you will see a progress bar...




...and when it's completed successfully, it says: "Upload done"

How to Hack Arduino Programs ("Sketches")

```
Blink | Arduino IDE 2.1.0
                                                                                         File Edit Sketch Tools Help
            Arduino Uno
              Dy Arcaro Guadatapi
              modified 8 Sep 2016
       17
              by Colby Newman
       18
       19
              This example code is in the public domain.
       20
       21
              https://www.arduino.cc/en/Tutorial/BuiltInExamples/Blink
       22
       23
       24
            // the setup function runs once when you press reset or power the board
            void setup() {
              // initialize digital pin LED BUILTIN as an output.
       27
              pinMode(LED BUILTIN, OUTPUT);
       28
       29
       30
            // the loop function runs over and over again forever
       31
            void loop() {
       32
              digitalWrite(LED BUILTIN, HIGH); // turn the LED on (HIGH is the voltage leve
       33
              delay(1000);
       34
                                                  // wait for a second
              digitalWrite(LED_BUILTIN, LOW); // turn the LED off by making the voltage LO
              delay(1000);
                                                  // wait for a second
       36
       37
       38
```

How to Hack Arduino Programs ("Sketches")




Many ways!


Here are just a few:

- Change blink rates
- External LED
- External motor
- External speaker
- External LED on Solderless breadboard
- More complex projects on Solderless breadboard


How to Hack Arduino Programs ("Sketches")




Solderless Breadboard




Solderless Breadboad with LED




Solderless Breadboad with LED and wires



Solderless Breadboad with LED and Resistor and wires





a Schematic How to Read


Arduino For Total Newbies

Mitch Altman (original TV-B-Gone hardware and firmware, modified TV-B-Gone Arduino design) Limore Fried (firmware modifications, kit design)




Johannes Schneemann (documentation)






Parts Pack Contents



If you want to:



https://cornfieldelectronics.com/cfe/u do it duino complete.php

To Download these slides

see the

Arduino for (4) Total Newbies

workshop web-page:

https://tinyurl.com/A4TNworkshop

Please Remember:

to
Wash your hands
after soldering

Arduino For Total Newbies w/TV-B-Gone as example project

Mitch Altman

Chief Scientist, Cornfield Electronics, San Francisco, CA

Inventor of TV-B-Gone universal remote controls

Co-founder of 3Ware (successful Silicon Valley startup)

Pioneer of VR (in the mid-1980s)

Founding mentor at HAX (1st and biggest hardware accelerator)

Co-founder of Noisebridge (San Francisco hackerspace)

email: mitch@CornfieldElectronics.com

site: www.CornfieldElectronics.com

facebook: maltman23

flickr: maltman23

WeChat: mitchaltman

Fediverse: @maltman23@mastodon.social

Patreon: mitchaltman



